


Conexiones reusables para mangueras SAE 100 R1 y SAE 100 R2

Hembra giratoria codo 45° rosca UNF asiento hembra JIC 37°


C1107 - C2107



Nº CODIGO SAE 100 R1	Nº CODIGO SAE 100 R2	Manguera Ø Interno	TAMAÑO ROSCA
1107-03-04	2107-03-04	3/16"	7/16"-20
1107-04-04	2107-04-04	1/4"	7/16"-20
1107-04-05	2107-04-05	1/4"	1/2"-20
1107-04-06	2107-04-06	1/4"	9/16"-18
1107-05-06	2107-05-06	5/16"	9/16"-18
1107-06-06	2107-06-06	3/8"	9/16"-18
1107-06-08	2107-06-08	3/8"	3/4"-16
1107-08-08	2107-08-08	1/2"	3/4"-16
1107-08-10	2107-08-10	1/2"	7/8"-14
1107-10-12	2107-10-12	5/8"	1 1/16"-12
1107-12-12	2107-12-12	3/4"	1 1/16"-12
1107-12-14	2107-12-14	3/4"	1 3/16"-12
1107-16-16	2107-16-16	1"	1 5/16"-12
1107-20-20	2107-20-20	1 1/4"	1 5/8"-12
1107-24-24	2107-24-24	1 1/2"	1 7/8"-12
1107-32-32	2107-32-32	2"	2 1/2"-12

Hembra giratoria codo 90° rosca BSP asiento hembra 37°

C1108 - C2108



Nº CODIGO SAE 100 R1	Nº CODIGO SAE 100 R2	Manguera Ø Interno	TAMAÑO ROSCA
1108-03-04	2108-03-04	3/16"	7/16"-20
1108-04-04	2108-04-04	1/4"	7/16"-20
1108-04-05	2108-04-05	1/4"	1/2"-20
1108-04-06	2108-04-06	1/4"	9/16"-18
1108-05-06	2108-05-06	5/16"	9/16"-18
1108-06-06	2108-06-06	3/8"	9/16"-18
1108-06-08	2108-06-08	3/8"	3/4"-16
1108-08-08	2108-08-08	1/2"	3/4"-16
1108-08-10	2108-08-10	1/2"	7/8"-14
1108-10-12	2108-10-12	5/8"	1 1/16"-12
1108-12-12	2108-12-12	3/4"	1 1/16"-12
1108-12-14	2108-12-14	3/4"	1 3/16"-12
1108-16-16	2108-16-16	1"	1 5/16"-12
1108-20-20	2108-20-20	1 1/4"	1 5/8"-12
1108-24-24	2108-24-24	1 1/2"	1 7/8"-12
1108-32-32	2108-32-32	2"	2 1/2"-12

"Poberaj SA se reserva el derecho de modificar las características y medidas de sus productos sin previo aviso".